

Frame bridges

Introduction and general aspects

Typologies



Examples

Modelling and analysis

Load-carrying behaviour



Soil-structure interaction



Strut frame geometry



V-Strut frame geometry

Specific topics

Prestressing



Detailing

Frame bridges

Introduction and general aspects

Frame bridges – Introduction and general aspects

Typologies

- Strictly speaking, **most bridges are framed structures**. While frame action is obviously relevant e.g. in arches and in girder bridges longitudinally stabilised by piers, it also matters in many other cases, where frame action is present in the longitudinal and/or transverse direction of the bridge.
- However, in bridge design, the term “**frame bridge**” is used only for structures exhibiting **pronounced frame action in the transfer of vertical loads**, which is similar to that of arches.



Frame bridges – Introduction and general aspects

Typologies

- **Frequent types of frame bridges** and their fields of application are illustrated on the right.
- Historically, frame bridges were often **idealised** to simplify global analysis **by introducing hinges**. This is still useful in preliminary design, but otherwise obsolete. However, reduced stiffnesses due to cracking (e.g. of the slender V-struts) must be accounted for.
- Frame bridges are often the most **economical solution for smaller spans**. Orthogonal and trapezoidal frames are particularly suitable for grade separations (flyovers, underpasses – modest structures in many cases).
- **Concrete strut frame bridges** are more expensive than girder or arch bridges for long spans due to the falsework cost (expensive for inclined piers). **Composite bridges, with inclined steel legs**, installed from the abutments, are economical for longer spans (see examples behind).

Frame bridge typologies

(and frequently used idealisation = hinges)


orthogonal frame



Constant depth solid cross-section (slab frame):
underpasses (e.g. train stations)

Haunched solid or box cross-section: low single-span bridges

trapezoidal frame




Economical for short span buried structures (underpasses)

strut frame

(inclined leg frame)


Sprengwerk



Economical alternative to arch for short and medium spans

V-strut frame

V-Stiel Rahmen



Often used for flyovers in the past


Frame bridges – Introduction and general aspects

Typologies

- Single span frames are particularly suitable for low bridges, since they allow minimising girder depth
→ **much higher slenderness possible** than for simply supported girders
- The depth of frame bridges at midspan is usually not sufficient for a box girder (access for maintenance)
→ in large span frames, use **open cross-section at midspan** and add bottom slab = **box girder in frame corners** (negative bending moment region) required)
- Single span frame bridges are always integral, strut frame bridges and V-strut frames are often integral or semi-integral as well
→ **high durability, low maintenance**
→ **no uplift problems** even at pronounced skew (V-strut frame bridge ends may, however, require regular pavement maintenance due to vertical movements of the bridge ends)

Frame bridge typologies – illustration from Menn (1990)


box-girder frame




slab frame



trapezoidal frame



strut frame (inclined leg frame) = Sprengwerk



Integral solution preferred, avoid expansion joint if possible!

V-strut frame = V-Stiel Rahmen



Frame bridges – Introduction and general aspects

Examples: Train station at Rikon


- Buried orthogonal frame for train station pedestrian underpass (a bridge ...)
- Precast elements (“Fanger-Elemente”)
- Installation in extremely short time (railway line interrupted)



Frame bridges – Introduction and general aspects

Examples: Flyover at Widnau

- Slender single span prestressed concrete frame bridge
- Span ca. 45 m, depth at midspan 1.10 m $\approx l / 41$
- Extremely complex geometry (variable skew and gradients)



Frame bridges – Introduction and general aspects

Examples: Hofbrücke (Aarebrücke) Innertkirchen

- Slender single span prestressed concrete slab frame,
- Clear span 42 m, length 51.40 m
- Replacing Maillart's bridge from 1934 to increase hydraulic capacity



Frame bridges – Introduction and general aspects

Examples: Stägmattabrücke, Lütschental


- Very slender ($L/48 \dots 24$) single span prestressed concrete slab frame
- Clear span 38.5 m, length 60 m, depth 0.80 m (midspan) ... 1.60 m (max)
- Replacing previous bridge destroyed in flood event 2005
- Built using overhead gantry (hydraulic capacity during construction)



Frame bridges – Introduction and general aspects

Examples: Myllysilta Bridge, Turku (this one was probably too slender)

- Extremely slender ($L/83 \dots 25$) prestressed concrete slab frame
- Clear span 71.2 m, depth 0.86 (midspan) $\dots 2.70$ m (max)
- “Repaired” 1977, replaced 2010 after excessive deflections (> 1 m)
- Cause for damage unclear (design / materials / foundations / repair ...?)



... Die Brücke wirkt wie ein Strich.
Vor Nachahmung wird gewarnt –
man muss hierfür wirklich ein
grosser Könnner sein!”

(Fritz Leonhardt, 1985)

Frame bridges – Introduction and general aspects

Examples: Brücke Schönenwerd

- Single span composite frame bridge with pronounced skew
- Prestressed concrete half-frame with cantilevers supporting the composite part of the span (four weathering steel box girders).



Frame bridges – Introduction and general aspects

Examples: Brücke Ruckhalde



- Skewed single span prestressed concrete trough frame bridge
- Minimum depth to cope with clearance requirements (changes in rail track alignment restricted by maximum slope and radius)



Frame bridges – Introduction and general aspects

Examples: Flyover at Düdingen

- Prefabricated V-strut frame overpass
- Standardised solution in CH, frequently used in motorways built in 1960-70s



Frame bridges – Introduction and general aspects

Examples: New Versamertobel Bridge

- prestressed concrete strut frame bridge, cast in situ
- Erected by (i) constructing legs (expensive falsework); (ii) supporting girder falsework on legs; (iii) casting girder




Frame bridges – Introduction and general aspects



Examples: New Versamertobel Bridge

- Concrete strut frame bridge, cast in situ
- Erected by (i) constructing legs (expensive falsework); (ii) supporting girder falsework on legs; (iii) casting girder

midspan



leg-girder connection



Frame bridges – Introduction and general aspects

Examples: Pont de la Dala

- Composite strut frame bridge
- Structurally very efficient system, very slender
- Erected by (i) tilting the legs (built vertically),
(ii) launching the girder longitudinally on the legs and
(iii) casting the deck on the girder




Frame bridges – **Introduction and general aspects**



Frame bridges – Introduction and general aspects

Examples: New Pont du Gueroz

- Composite strut frame bridge
- Structurally very efficient system, very slender
- Erected by (i) tilting the legs (built vertically), (ii) launching the girder longitudinally on the legs and (iii) casting the deck on the girder



Frame bridges – Introduction and general aspects



Frame bridges – Introduction and general aspects




Frame bridges

Modelling and analysis

Frame bridges – Modelling and analysis

Load-carrying behaviour



- Historically, frames were not only analysed, but also built with hinges to avoid restraint due to imposed deformation, settlements etc. Today, hinges are avoided (durability); the **three-hinged frame** is used here only to illustrate the behaviour (top row figures):
 - **pronounced frame action** = strongly inclined reactions, large hogging moments at frame corners
- If the legs are haunched, reducing the depth towards the foundation, behaviour is similar to a **two-hinged frame** (figures in middle row):
 - **reduced frame action compared to three-hinged frame** (lower hogging moments, less inclined reactions)
- However, frames are usually (partially) fixed at the base (bottom row figures):
 - **similar hogging moments as two-hinged frame**
 - **bending moments in legs change sign**
 - **higher shear forces in legs than for two-hinged arch** (inclination of reactions in-between two- and three-hinged frame)



Frame bridges – Modelling and analysis

Soil-structure interaction


- In reality, frames are typically neither fixed nor hinged at the base, but elastically clamped
 - behaviour between fixed and two-hinged frame
- Furthermore, the foundations are flexible, particularly in the horizontal direction
 - frame action significantly reduced in soft soil
 - model foundation with elastic springs (see substructure)
- In short-span buried frames (underpasses), the backfill is often modelled as load (top figure).
- In abutment walls acting as legs of large span frames, the backfill can be modelled as follows:
 - apply permanent earth pressure as load (top figure)
 - model backfill using elastic springs for all other loads (bottom figure)
 - check that no tension results and passive pressure is not exceeded (relevant value = combination of both models)



Frame bridges – Modelling and analysis

Strut frame geometry – symmetric and skew symmetric case


- In strut frames, the geometry (leg inclination, girder spans) should be anti-funicular, i.e., correspond to the thrust line of the dead load (girder + upper part of legs):
 - bending moments in girder \approx **continuous girder**
 - “zero” girder deflection at inclined pier connection (except axial deformation of legs)
 - **no horizontal movements under dead load**
- Aesthetically, the connection line of the leg foundations, resp. the leg intersection with the ground, should (as the springing line of arches) be parallel to the girder
- In either case, **graphic statics** is useful to understand the response and determine the geometry (considering the legs as pin-jointed members)
 - **equal horizontal component of leg forces** by equilibrium
 - equal vertical support reaction = equal leg inclination
 - slightly different leg inclination in skew symmetric case



Frame bridges – Modelling and analysis

Strut frame geometry – non-symmetric case


- In **non-symmetrical strut frames**, choosing an anti-funicular geometry is more important than in symmetric cases, where “symmetric” deviations of the geometry merely cause changes in bending moments, see next slide
- Graphic statics is particularly useful to define the right geometry:
 - choose **girder span layout** ($\rightarrow c_1+c_2$ given)
 - determine **support reactions** in continuous girder
 - select first leg foundation** = inclination \rightarrow inclination of other leg and position of foundation follow from $G_1 \cdot c_1 + G_2 \cdot c_2$
 - iterate until second leg foundation matches topography and layout is aesthetically satisfactory



Frame bridges – Modelling and analysis

Strut frame geometry – non-symmetric case



- If the geometry of the struts is not anti-funicular in non-symmetric strut frames (lower figure)
 - large horizontal displacements under dead load
 - large girder deflection at inclined pier connections
 - bending moments in girder \neq continuous girder (sagging moment in large end span, already critical in anti-funicular case, increases)
- The behaviour can be explained by observing that equal strut inclinations cause equal strut forces (due to horizontal equilibrium), i.e., the vertical component R (equal for both legs) is
 - smaller than G_1 (left leg to girder connection)
 - larger than G_2 (right leg to girder connection)
- differences between vertical component of leg forces and (G_1, G_2) must be carried by the girder in bending



Frame bridges – Modelling and analysis

V-strut frame geometry – symmetric case



- Similar observations apply to the geometry of V-strut frames, in both the symmetrical case (figures on this and next slide) and non-symmetrical case.
- Depending on the span arrangement and the foundation stiffness (model with horizontal spring), uplift reactions occur at the end supports
 - rear legs in tension
 - frequent case in motorway flyovers (main span maximised / side spans minimised)
 - prestressed legs are a frequent case of damage (improper grouting, see next slides)
- V-strut legs are often embedded in the backfill / embankment
 - protect V-struts from earth pressure (half tube / soft layer above legs before backfilling)



Frame bridges – Modelling and analysis

V-strut frame geometry – skew symmetric case

- As in strut frames, it is aesthetically favourable if the connection line of the leg foundations, resp. the leg intersection with the ground, is parallel to the girder.




Frame bridges

Prestressing

Frame bridges – Prestressing

Prestressing concept and tendon geometry: (V)-strut frames

- **Strut frame and V-Strut frame girders** can be prestressed as conventional bridge girders, accounting for the fact that
 - in both cases, the **midspan section of the girder is compressed** by the frame action (beneficial)
 - in V-strut frames, the **side spans OF THE GIRDER (above each V) are subjected to tension**, which requires additional prestressing
- Depending on the span layout and support stiffness (model with springs), **the rear legs of V-strut frames are often subject to tension**, at least under traffic loads at midspan
 - **prestress rear legs**
 - **proper grouting essential for durability**
 - upper end of struts is difficult to grout: **use re-/post-grouting (nachinjizierbare Spannglieder)**




Frame bridges – Prestressing


Prestressing concept and tendon geometry: Single span frames

- **Single span frames** should at least be fully prestressed for permanent load (no decompression under permanent load).
 - Large span, slender single span frames are **sensitive to deflections and moment redistributions** due to
 - long-term effects (prestressing force losses)
 - horizontal deformations of foundations
 - provide strong prestressing, preferably **fully balancing the permanent loads** (“formtreue Vorspannung”) to ensure concentric compression at $t = \infty$ under permanent load and accounting for foundation flexibility
 - **Deviation forces in variable depth girders** may be estimated as illustrated in the figure
 - “Parabolic” **tendon geometry** can be defined using this approach as well
 - define geometry in equivalent girder with horizontal axis
 - transfer eccentricities with respect to real geometry
- (method is applicable in any variable depth girder, e.g. for continuity tendons in cantilever-constructed girders)

Girder and tendon profile



Idealised girder and tendon profile



Frame bridges


Detailing

Frame bridges – Detailing


(V-) Strut frame bridges: Strut-girder connection

- **Vertical diaphragms** are commonly used at the connection of the inclined piers to the girder
- In box girders, provide **passage for inspection**
- Ensure **force flow**
 - include **moment transfer** (even if piers are modelled as pin-jointed members, they transfer bending moments)
 - use **strut-and-tie model** for detailing (internal actions referred to **system axes** yield only limited insight in local force transfer)


Section S-S




Section S-S



Section A-A



Section B-B




Frame bridges – Detailing

Single span frames: Abutment walls

- Due to the flexibility of the foundations, **bending moments** in the piers = abutment walls of single span frames typically **decrease strongly towards the base** (behaviour close to **two-hinged frame**)
 - taper abutment walls towards the base
 - often, abutment walls are provided with variable depth ribs
- Abutment walls can usually be provided with sufficient depth
 - no prestressing of walls, even if girder is prestressed (otherwise, detailing is demanding)
- In **slab frames** (slab and walls as solid slabs, economical up to ca. 15 m span), design is straightforward (2D problem)
- If the **abutment wall is provided with ribs**, the compressive forces in the slab between ribs need to be transferred (→ small rib spacing, solid section at top of abutment), similar as in a box girder frame (next slide)


bending moments
in two-hinged
frame



slab frame



solid slab,
abutment walls
with ribs



prestressed slab,
abutment walls
with ribs




Frame bridges – Detailing

Single span frames: Frame corners


- The frame corners are subject to **closing moments**
 - much **less critical than opening moments**, see lecture Advanced Structural Concrete)
 - use strut-and-tie models and stress fields for a consistent dimensioning and detailing (figure)
- Similarly, in **box girder frames**, a **diagonal compression slab** is usually required (figure)
- Skew frames rotate in plan (see chapter on skew bridges)

force flow in slab
frame corner
(simplified, for
equal depth of
wall and slab)



force flow in box
girder frame
corner


diagonal slab
(compression
diagonal in frame
corner AND
transverse
spreading of
compressive
force in plan)



Frame bridges – Detailing

Particularities of trough frames

- Trough frames are appropriate in situations with very **limited available depth** (due to clearance and alignment requirements)
- In their design, it must be observed that the **trough slab cannot be activated in compression** in the frame corner, unless a continuing slab providing load spreading is provided (abutment wall cannot resist this high force in transverse shear)
- In turn, the **wing walls can be activated for moment transfer** (larger depth, no prestressing required), design with stress fields



does not act as compression zone in frame corner unless slab continues



Frame bridges – Prestressing and detailing

